

## **HAND SANITIZER STAND DISPOSAL**

If the hand sanitizer station no longer works:

- 1) Remove the batteries from the station stand.  
\*Batteries are considered hazardous waste and may not be thrown into the trash.
- 2) Remove the hand sanitizer reservoir and if necessary, drain to empty any residue into a usable hand sanitizer bottle. Then rinse with water to ensure it is empty.  
\*\*Excess hand sanitizer should not be rinsed down the drain. It should be collected and used as much as possible.
- 3) Discard both the station stand and the rinsed reservoir in the trash.
- 4) Recycle the battery through a battery recycling program. This may be the mall battery recycling station, through the Luxottica battery mail-back bucket (if available in store already), or with a local battery recycling location (such as Best Buy, Batteries +, etc.).
- 5) If you have any questions, contact [RetailSafety@luxotticaretail.com](mailto:RetailSafety@luxotticaretail.com).